

INSTRUCTION GUIDE

FIX-IT REPAIR RING



1

Remove broken/corroded sections of the existing ring and clean away any remaining wax from the existing flange. Dry fit the Fix-It Repair ring in the desired location to ensure correct alignment and mark anchoring points for reference. (Note: Additional holes may need to be drilled into a cast iron flange ring to create alignment with new repair ring).



2

Apply a liberal bead of silicone on top of the existing flange.

3

Insert T-Bolts into existing flange slots and press the repair ring down into the desired location for correct bolt alignment. Secure it to the subfloor using appropriate screws and anchors.

4

Do not wipe off excess silicone until the repair ring has been secured to the subfloor.
