

INSTALLATION INSTRUCTIONS

Oatey®

ANGLED WALL BRACKET PEX & CPVC KIT

- 1 Install the bracket to the studs by adjusting the angled wall bracket ears to desired mounting position. Use screws or nails at each end.
- 2 Insert PEX tubing into the PEX Bend or insert CPVC or copper pipe into rubber grommet.
- 3 Install PEX bend or CPVC/copper pipe with grommet into the metal clamps on the bracket and tighten screw.

NOTICE D'INSTALLATION

NÉCESSAIRE PEX ET CPVC DE SUPPORT MURAL COUDÉ

- 1 Fixez le support aux montants en ajustant les pattes du support mural coudé à la position de montage désirée. Utilisez des vis ou des clous à chaque extrémité.
- 2 Insérez le tuyau en CPVC ou cuivre dans l'œillet en caoutchouc.
- 3 Posez le coude PEX ou le tuyau en CPVC/cuivre avec œillet dans les colliers en métal sur le support et serrez la vis.

INSTRUCCIONES DE INSTALACIÓN

JUEGO DE SOPORTE DE PARED EN ÁNGULO PEX Y CPVC

- 1 Instalar el soporte en los montantes ajustando las orejas del soporte de pared en ángulo a la posición de montaje deseada. Usar tornillos o clavos en cada extremo.
- 2 Insertar el tubo de CPVC o de cobre en el aro de refuerzo de caucho.
- 3 Instalar el codo PEX o el tubo de CPVC/cobre con el aro de refuerzo en las abrazaderas metálicas en el soporte y apretar el tornillo.

