

# INSTRUCTION GUIDE

## LA CODE



**1** Apply a thread sealant to the waste connector threads.

---

**2** Tighten the elbow onto the waste connector threads.

---

**3** Slide the slip joint nut then washer up the tailpiece.

---

**4** Connect the J-Bend to the elbow and tailpiece.

---

**5** Tighten the slip joint and elbow nuts.

---

**6** Check for leaks. If leaks occur, tighten another  $\frac{1}{4}$  turn.

