

# INSTRUCTION GUIDE

## NY CODE



**1** Apply a thread sealant to the waste connector threads.

---

**2** Tighten the trap onto the waste connector threads with the trap ending in a vertical position.

---

**3** Slide the slip joint nut then washer up the tailpiece, then insert into the trap and tighten.

---

**4** Check for leaks. If leaks occur, tighten another  $\frac{1}{4}$  turn.

