

# INSTRUCTION GUIDE

## BATHROOM P-TRAP

Oatey

**1** Measure and cut the wall tube to the desired length.

---

**2** Position the slip nuts and slip washers onto the wall tube.

---

**3** Insert the wall tube into the waste connector and hand tighten the existing waste connector slip nut.

---

**4** Position the slip nut and slip washer onto the vertical tailpiece.

---

**5** Place J-bend onto the wall tube and tailpiece, and hand tighten the slip nuts for alignment.

---

**6** Fully tighten all slip nuts and test for leaks.

