

INSTRUCTION GUIDE

EXTENSION TUBE

Oatey

1 Measure and cut the extension to the desired length. Deburr the tube end.

2 Install the extension over the existing tube end.

a For slip joint extensions: Slide the nut then washer up the existing tube and secure to the extension. If connecting a 1-1/2 in. extension to an existing 1-1/4 in. tube, use a reducing washer to make the transition.

b For solvent weld extensions: Prime and cement the pipe and fitting using approved products for the extension material. (Do not use primer on ABS.)

3 Tighten the nuts, being sure not to overtighten.

4 Check for leaks. If leaks occur, tighten another ¼ turn.

