

INSTRUCTION GUIDE

NUTS AND WASHERS



1 Deburr the end of the tube, if necessary.

2 For a slip joint connection: Slide the nut over the tube, then slide the washer over the tube with the beveled edge towards the female slip joint connection. If using a 1-1/2 in. nut with a 1-1/4 in. tube, use a reducing washer to make the transition.

3 For a flanged connection: Slide the nut up the tube, then insert the flanged washer into the flange of the tailpiece.

4 Tighten and check for leaks. If leaks occur, tighten another 1/4 turn.

