INSTRUCTION GUIDE ESCUTCHEON PLATE



Check that flange/plate size matches the pipe diameter.
Place flange/plate around the pipe.
Secure flange/plate around the wall, floor, or ceiling pipe opening.



©2021 Oatey SCS. All Rights Reserved. This information is based on data believed to be reliable but Oatey makes no warranties, express or implied, as to its accuracy and assumes no liability arising out of its use. The data listed falls within the normal range of product properties but should not be used to establish specification limits or used alone as the basis of design. Oatey's liability to purchasers is expressly limited to the terms and conditions of sale. Oatey is trademark of Oatey Co. All other trademarks can be found www.Oatey.com.