

INSTRUCTION GUIDE

QUIET PIPES® HAMMER ARRESTOR

Oatey

1 Turn off the water supply to the valve.

2 Cut water line and place supplied compression nut and ferrule ring on both ends of the pipe.

3 Insert both ends of the pipe into the openings of the Quiet Pipes® Hammer Arrestor and secure compression nuts to the hammer arrestor using wrenches. Use one wrench to stabilize the hammer arrestor and prevent movement while using another to tighten compression nuts.

4 Turn the water on and check for leaks.

